

# CONTENTS

## SECTION 1 GENERAL

Group 1 Safety Hints .....	1-1
Group 2 Specifications .....	1-10
Group 3 Operational Checkout Record Sheet .....	1-24

## SECTION 2 ENGINE

Group 1 Structure and Function .....	2-1
Group 2 Engine speed and Stall rpm .....	2-7

## SECTION 3 POWER TRAIN SYSTEM

Group 1 Structure and Function (fault code) .....	3-1
Group 2 Operational Checks and Troubleshooting .....	3-78
Group 3 Test and Adjustments .....	3-90
Group 4 Disassembly and Assembly .....	3-92

## SECTION 4 BRAKE SYSTEM

Group 1 Structure and Function .....	4-1
Group 2 Operational Checks and Troubleshooting .....	4-32
Group 3 Tests and Adjustments .....	4-39
Group 4 Disassembly and assembly .....	4-41

## SECTION 5 STEERING SYSTEM

Group 1 Structure and Function .....	5-1
Group 2 Operational Checks and Troubleshooting .....	5-8
Group 3 Tests and Adjustments .....	5-16
Group 4 Disassembly and Assembly .....	5-21

## SECTION 6 WORK EQUIPMENT

Group 1 Structure and Function .....	6-1
Group 2 Operational Checks and Troubleshooting .....	6-34
Group 3 Tests and Adjustments .....	6-45

## **SECTION 7 ELECTRICAL SYSTEM**

Group 1 Component Location .....	7-1
Group 2 Electrical Circuit .....	7-3
Group 3 Electrical Component Specification .....	7-22
Group 4 Connectors .....	7-29
Group 5 Troubleshooting .....	7-52