

CONTENTS

SECTION 1 GENERAL

Group 1 Safety Hints	1-1
Group 2 Specifications	1-9

SECTION 2 STRUCTURE AND FUNCTION

Group 1 Pump Device	2-1
Group 2 Main Control Valve	2-15
Group 3 Swing Device	2-46
Group 4 Travel Motor	2-57
Group 5 RCV Lever	2-63
Group 6 Accelerator Pedal	2-70
Group 7 Brake Device	2-71
Group 8 Transmission	2-73
Group 9 Travel Control Valve	2-80
Group 10 Steering Valve	2-82
Group 11 Front Axle and Rear Axle	2-84

SECTION 3 HYDRAULIC SYSTEM

Group 1 Hydraulic Circuit	3-1
Group 2 Main Circuit	3-4
Group 3 Pilot Circuit	3-7
Group 4 Single Operation	3-18
Group 5 Combined Operation	3-33

SECTION 4 ELECTRICAL SYSTEM

Group 1 Component Location	4-1
Group 2 Electrical Circuit	4-3
Group 3 Electrical Component Specification	4-25
Group 4 Connectors	4-37

SECTION 5 MECHATRONICS SYSTEM

Group 1 Outline	5-1
Group 2 Mode selection System	5-3

Group 3 Automatic Deceleration System	5-6
Group 4 Power Boost System	5-7
Group 5 Travel Speed Control System	5-8
Group 6 Automatic Warming Up Function	5-9
Group 7 Engine Overheat Prevention Function	5-10
Group 8 Variable Power Control System	5-11
Group 9 Attachment Flow Control System	5-12
Group 10 Intelligent Power Control System	5-13
Group 11 Anti-Restart System	5-15
Group 12 Self-Diagnostic System	5-16
Group 13 Engine Control System	5-63
Group 14 EPPR Valve	5-64
Group 15 Monitoring System	5-69
Group 16 Fuel Warmer System	5-117
Group 17 1 or 2-Way Optional Piping Pressure Removal System	5-118

SECTION 6 TROUBLESHOOTING

Group 1 Before Troubleshooting	6-1
Group 2 Hydraulic and Mechanical System	6-4
Group 3 Electrical System	6-26
Group 4 Mechatronics System	6-42
Group 5 Air conditioner and Heater System	6-78

SECTION 7 MAINTENANCE STANDARD

Group 1 Operational Performance Test	7-1
Group 2 Major Components	7-19
Group 3 Track and Work Equipment	7-28

SECTION 8 DISASSEMBLY AND ASSEMBLY

Group 1 Precaution	8-1
Group 2 Tightening Torque	8-4
Group 3 Pump Device	8-7
Group 4 Main Control Valve	8-33
Group 5 Swing Device	8-63
Group 6 Travel Motor	8-93
Group 7 Transmission	8-117

Group 8 Steering Valve	8-214
Group 9 Front Axle	8-239
Group 10 Rear Axle	8-310
Group 11 RCV Lever	8-352
Group 12 Turning Joint	8-366
Group 13 Boom, Arm, Bucket, Dozer and Outrigger Cylinders	8-372
Group 14 Work Equipment	8-401