

SECTION 1 GENERAL

Group 1 Safety Hints	1-1
Group 2 Specifications	1-10

SECTION 2 STRUCTURE AND FUNCTION

Group 1 Pump Device	2-1
Group 2 Main Control Valve	2-21
Group 3 Swing Device	2-52
Group 4 Travel Device	2-63
Group 5 RCV Lever	2-76
Group 6 RCV Pedal	2-83

SECTION 3 HYDRAULIC SYSTEM

Group 1 Hydraulic Circuit	3-1
Group 2 Main Circuit	3-4
Group 3 Pilot Circuit	3-7
Group 4 Single Operation	3-16
Group 5 Combined Operation	3-28

SECTION 4 ELECTRICAL SYSTEM

Group 1 Component Location	4-1
Group 2 Electrical Circuit	4-3
Group 3 Electrical Component Specification	4-23
Group 4 Connectors	4-34

SECTION 5 MECHATRONICS SYSTEM

Group 1 Outline	5-1
Group 2 Mode selection System	5-3
Group 3 Automatic Deceleration System	5-6
Group 4 Power Boost System	5-7
Group 5 Travel Speed Control System	5-8
Group 6 Automatic Warming Up Function	5-9
Group 7 Engine Overheat Prevention Function	5-10

Group 8	Variable Power Control System	5-11
Group 9	Attachment Flow Control System	5-12
Group 10	Intelligent Power Control System.....	5-13
Group 11	Anti-Restart System	5-15
Group 12	Self-Diagnostic System	5-16
Group 13	Engine Control System	5-62
Group 14	EPPR Valve	5-63
Group 15	Monitoring System	5-68
Group 16	Fuel Warmer System	5-105
Group 17	1 or 2-Way Optional Piping Pressure Removal System	5-106

SECTION 6 TROUBLESHOOTING

Group 1	Before troubleshooting	6-1
Group 2	Hydraulic and Mechanical System	6-4
Group 3	Electrical System	6-24
Group 4	Mechatronics System	6-42
Group 5	Air conditioner and Heater System	6-71

SECTION 7 MAINTENANCE STANDARD

Group 1	Operational Performance Test	7-1
Group 2	Major Components	7-21
Group 3	Track and Work Equipment	7-29

SECTION 8 DISASSEMBLY AND ASSEMBLY

Group 1	Precaution	8-1
Group 2	Tightening Torque	8-3
Group 3	Pump Device	8-7
Group 4	Main Control Valve	8-32
Group 5	Swing Device	8-46
Group 6	Travel Device	8-78
Group 7	RCV Lever	8-110
Group 8	Turning Joint	8-124
Group 9	Boom, Arm and Bucket Cylinder	8-129
Group 10	Undercarriage	8-148
Group 11	Work Equipment	8-160