

SECTION 1 GENERAL

Group 1 Safety Hints	1-1
Group 2 Specifications	1-10

SECTION 2 STRUCTURE AND FUNCTION

Group 1 Pump Device	2-1
Group 2 Main Control Valve	2-22
Group 3 Swing Device (machine serial no. : -#0025)	2-56
Swing Device (machine serial no. : #0026-)	2-67-1
Group 4 Travel Device (type 1)	2-68
Travel Device (type 2, machine serial no. : #0190-)	2-80-1
Group 5 RCV Lever	2-81
Group 6 RCV Pedal	2-88

SECTION 3 HYDRAULIC SYSTEM (OLD VERSION)

Group 1 Hydraulic Circuit	3-1
Group 2 Main Circuit	3-3
Group 3 Pilot Circuit	3-6
Group 4 Single Operation	3-15
Group 5 Combined Operation	3-25

HYDRAULIC SYSTEM (CURRENT VERSION)

Group 1 Hydraulic Circuit	3-33-1
Group 2 Main Circuit	3-33-7
Group 3 Pilot Circuit	3-33-10
Group 4 Single Operation	3-33-19
Group 5 Combined Operation	3-33-29

SECTION 4 ELECTRICAL SYSTEM

Group 1 Component Location	4-1
Group 2 Electric Circuit	4-3
Group 3 Electrical Component Specification	4-23
Group 4 Connectors	4-36

SECTION 5 MECHATRONICS SYSTEM

Group 1 Outline	5-1
Group 2 Mode selection System	5-3
Group 3 Automatic Deceleration System	5-6
Group 4 Power Boost System	5-7
Group 5 Travel Speed Control System	5-8
Group 6 Automatic Warming Up System	5-9
Group 7 Engine Overheat Prevention System	5-10
Group 8 Variable Power Control System	5-11
Group 9 Attachment Flow Control System	5-12
Group 10 Boom Floating Control System	5-13
Group 11 Intelligent Power Control System	5-14
Group 12 Anti-Restart System	5-16
Group 13 Self-Diagnostic System	5-17
Group 14 Engine Control System	5-62
Group 15 EPPR (Electro Proportional Pressure Reducing) Valve	5-63
Group 16 Monitoring System	5-68
Group 17 Fuel Warmer System	5-108
Group 18 1 or 2-Way Optional Piping Pressure Removal System	5-110
Group 19 2DMG+ System	5-111

SECTION 6 TROUBLESHOOTING

Group 1 Before Troubleshooting	6-1
Group 2 Hydraulic and Mechanical System	6-4
Group 3 Electrical System	6-25
Group 4 Mechatronics System	6-44
Group 5 Air con & Heater System	6-74

SECTION 7 MAINTENANCE STANDARD

Group 1 Operational Performance Test	7-1
Group 2 Major Components	7-21
Group 3 Track and Work Equipment	7-36

SECTION 8 DISASSEMBLY AND ASSEMBLY

Group 1 Precaution	8-1
Group 2 Tightening Torque	8-4
Group 3 Pump Device	8-7

Group 4	Main Control Valve	8-31
Group 5	Swing Device	8-52
Group 6	Travel Device (type 1)	8-74
	Travel Device (type 2, machine serial no. : #0190-)	8-105-1
Group 7	RCV Lever	8-106
Group 8	Turning Joint	8-120
Group 9	Boom, Arm and Bucket Cylinder	8-125
Group 10	Undercarriage	8-147
Group 11	Work Equipment	8-159