

CONTENTS

SECTION 1 GENERAL

| | |
|------------------------------|------|
| Group 1 Safety Hints | 1-1 |
| Group 2 Specifications | 1-10 |

SECTION 2 STRUCTURE AND FUNCTION

| | |
|----------------------------------|------|
| Group 1 Pump Device | 2-1 |
| Group 2 Main Control Valve | 2-20 |
| Group 3 Swing Device | 2-46 |
| Group 4 Travel Device | 2-58 |
| Group 5 RCV Lever | 2-72 |
| Group 6 RCV Pedal | 2-79 |

SECTION 3 HYDRAULIC SYSTEM

| | |
|----------------------------------|------|
| Group 1 Hydraulic Circuit | 3-1 |
| Group 2 Main Circuit | 3-2 |
| Group 3 Pilot Circuit | 3-5 |
| Group 4 Single Operation | 3-14 |
| Group 5 Combined Operation | 3-24 |

SECTION 4 ELECTRICAL SYSTEM

| | |
|--|------|
| Group 1 Component Location | 4-1 |
| Group 2 Electric Circuit | 4-3 |
| Group 3 Electrical Component Specification | 4-23 |
| Group 4 Connectors | 4-34 |

SECTION 5 MECHATRONICS SYSTEM

| | |
|---|------|
| Group 1 Outline | 5-1 |
| Group 2 Mode selection System | 5-3 |
| Group 3 Automatic Deceleration System | 5-6 |
| Group 4 Power Boost System | 5-7 |
| Group 5 Travel Speed Control System | 5-8 |
| Group 6 Automatic Warming Up System | 5-9 |
| Group 7 Engine Overheat Prevention System | 5-10 |
| Group 8 Variable power Control System | 5-11 |
| Group 9 Attachment Flow Control System | 5-12 |
| Group 10 Boom Floating Control System | 5-13 |

| | |
|---|------|
| Group 11 Intelligent Power Control System | 5-14 |
| Group 12 Anti-Restart System | 5-16 |
| Group 13 Self-Diagnostic System | 5-17 |
| Group 14 Engine Control System | 5-56 |
| Group 15 EPPR Valve | 5-57 |
| Group 16 Monitoring System | 5-62 |
| Group 17 Fuel Warmer System | 5-99 |

SECTION 6 TROUBLESHOOTING

| | |
|---|------|
| Group 1 Before Troubleshooting | 6-1 |
| Group 2 Hydraulic and Mechanical System | 6-4 |
| Group 3 Electrical System | 6-24 |
| Group 4 Mechatronics System | 6-40 |

SECTION 7 MAINTENANCE STANDARD

| | |
|--|------|
| Group 1 Operational Performance Test | 7-1 |
| Group 2 Major Components | 7-20 |
| Group 3 Track and Work Equipment | 7-30 |

SECTION 8 DISASSEMBLY AND ASSEMBLY

| | |
|---|-------|
| Group 1 Precaution | 8-1 |
| Group 2 Tightening Torque | 8-4 |
| Group 3 Pump Device | 8-7 |
| Group 4 Main Control Valve | 8-31 |
| Group 5 Swing Device | 8-51 |
| Group 6 Travel Device | 8-76 |
| Group 7 RCV Lever | 8-101 |
| Group 8 Turning Joint | 8-115 |
| Group 9 Boom, Arm and Bucket Cylinder | 8-120 |
| Group 10 Undercarriage | 8-137 |
| Group 11 Work Equipment | 8-149 |

SECTION 9 COMPONENT MOUNTING TORQUE

| | |
|----------------------------------|------|
| Group 1 Introduction guide | 9-1 |
| Group 2 Engine system | 9-2 |
| Group 3 Electric system | 9-4 |
| Group 4 Hydraulic system | 9-6 |
| Group 5 Undercarriage | 9-9 |
| Group 6 Structure | 9-10 |
| Group 7 Work equipment | 9-14 |