

CONTENTS

SECTION 1 GENERAL

Group 1 Safety Hints	1-1
Group 2 Specifications	1-10

SECTION 2 STRUCTURE AND FUNCTION

Group 1 Pump Device	2-1
Group 2 Main Control Valve	2-23
Group 3 Swing Device	2-56
Group 4 Travel Device	2-66
Group 5 RCV Lever	2-83
Group 6 RCV Pedal	2-90

SECTION 3 HYDRAULIC SYSTEM

Group 1 Hydraulic Circuit	3-1
Group 2 Main Circuit	3-2
Group 3 Pilot Circuit	3-5
Group 4 Single Operation	3-11
Group 5 Combined Operation	3-21

SECTION 4 ELECTRICAL SYSTEM

Group 1 Component Location	4-1
Group 2 Electric Circuit	4-3
Group 3 Electrical Component Specification	4-21
Group 4 Connectors	4-29

SECTION 5 MECHATRONICS SYSTEM

Group 1 Outline	5-1
Group 2 Mode Selection System	5-3
Group 3 Automatic Deceleration System	5-6
Group 4 Power Boost System	5-7
Group 5 Travel Speed Control System	5-8
Group 6 Automatic Warming Up System	5-9
Group 7 Engine Overheat Prevention System	5-10
Group 8 Variable power control system	5-11

Group 9 Attachment flow control system	5-12
Group 10 Anti-restart system	5-13
Group 11 Self-Diagnostic System	5-14
Group 12 Engine Control System	5-24
Group 13 EPPR (Electro Proportional Pressure Reducing) Valve	5-25
Group 14 Monitoring System	5-28
Group 15 Fuel warmer system	5-51

SECTION 6 TROUBLESHOOTING

Group 1 Before Troubleshooting	6-1
Group 2 Hydraulic and Mechanical System	6-4
Group 3 Electrical System	6-24
Group 4 Mechatronics System	6-40

SECTION 7 MAINTENANCE STANDARD

Group 1 Operational Performance Test	7-1
Group 2 Major Components	7-21
Group 3 Track and Work Equipment	7-32

SECTION 8 DISASSEMBLY AND ASSEMBLY

Group 1 Precaution	8-1
Group 2 Tightening Torque	8-4
Group 3 Pump Device	8-7
Group 4 Main Control Valve	8-30
Group 5 Swing Device	8-69
Group 6 Travel Device	8-90
Group 7 RCV Lever	8-135
Group 8 Turning Joint	8-149
Group 9 Boom, Arm and Bucket Cylinder	8-154
Group 10 Undercarriage	8-171
Group 11 Work Equipment	8-183

SECTION 9 COMPONENT MOUNTING TORQUE

Group 1 Introduction guide	9-1
Group 2 Engine system	9-2
Group 3 Electric system	9-5

Group 4 Hydraulic system	9-7
Group 5 Undercarriage	9-10
Group 6 Structure	9-12
Group 7 Work equipment	9-18