Group	1 Safety hints	1-1
Group	2 Specifications	1-5
Group	3 Periodic replacement	1-18

GROUP 1 SAFETY HINTS

Careless performing of the easy work may cause injuries.

Take care to always perform work safely, at least observing the following.

 Oil is a dangerous substance. Never handle oil, grease or oily clothes in places where there is any fire of flame.

As preparation in case of fire, always know the location and directions for use of fire extinguishers and other fire fighting equipment.

- Wear well-fitting helmet, safety shoes and working clothes. When drilling, grinding or hammering, always wear protective goggles. Always do up safety clothes properly so that they do not catch on protruding parts of machines. Do not wear oily clothes. When checking, always release battery plug.
- Flames should never be used instead of lamps. Never use a naked flame to check leaks or the level of oil or electrolyte.







D50ASF02

D50ASF04

- A Be particularly careful when removing the radiator cap and the hydraulic oil tank filler cap, if this is done immediately after using the machine, there is a danger that boiled oil may spurt out.
- The procedure for releasing the hydraulic pressure is as follows : lower the fork to the ground, and stop the engine (Motor), move the control levers to each position two or three times.
- When working on top of the machine, be careful not to lose your balance and fall.





 Hand a caution sign in the operator's compartment (For example **Do not start** or **Maintenance in** progress).

This will prevent anyone from starting or moving the machine by mistake.

A It is extremely dangerous to try to check the fan belt tension while he engine is running.

When inspecting the engine is running parts, or near such parts, always stop the engine first.

Before checking or servicing accumulator or piping, depress brake pedal repeatedLy to release pressure.

Park the machine on firm, flat ground.
 Lower the fork to the ground and stop the engine.

Return each lever to **NEUTRAL** and apply the brake lock.





 Immediately remove any oil or grease on the floor of the operator's compartment, or on the handrail. It is very dangerous if someone slips while on the machine.

 When working with others, choose a group leader and work according to his instructions.
 Do not perform any maintenance beyond the agreed work.

- Unless you have special instructions to the contrary, maintenance should always be carried out with the engine stopped. If maintenance is carried out with the engine running, there must be two men present : one sitting in the operator's seat and the other one performing the maintenance. In such a case, never touch any moving part.
- Always remember that the hydraulic oil circuit is under pressure. When feeding or draining the oil or carrying out inspection and maintenance, release the pressure first.







- Thoroughly clean the machine. In particular, be careful to clean the filler caps, grease fittings and the area around the dipsticks. Be careful not to let any dirt or dust into the system.
- · Always use HYUNDAI Forklift genuine parts for replacement.
- Always use the grades of grease and oil recommended by HYUNDAI Forklift. Choose the viscosity specified for the ambient temperature.
- · Always use pure oil or grease, and be sure to use clean containers.
- When checking or changing the oil, do it in a place free of dust, and prevent any dirt from getting into the oil.
- [.] Before draining the oil, warm it up to a temperature of 30 to 40°C.
- [.] After replacing oil, filter element or strainer, bleed the air from circuit.
- [.] When the strainer is located in the oil filler, the strainer must not be removed while adding oil.
- When changing the oil filter, check the drained oil and filter for any signs of excessive metal particles or other foreign materials.
- [•] When removing parts containing O-ring, gaskets or seals, clean the mounting surface and replace with new sealing parts.
- · After injecting grease, always wipe off the oil grease that was forced out.
- [•] Do not handle electrical equipment while wearing wet places, as this can cause electric shock.
- [.] During maintenance do not allow any unauthorized person to stand near the machine.
- [•] Be sure you fully understand the contents of the operation. It is important to prepare necessary tools and parts and to keep the operating area clean.
- When checking an open gear case there is a risk of dropping things in. Before removing the covers to inspect such cases, empty everything from your pockets. Be particularly careful to remove wrenches and nuts.
- Way to use dipstick

Push the dipstick fully into the guide, and then pull out.

Carrying out other difficult maintenance work carelessly can cause unexpected accidents. If you consider the maintenance is too difficult, always request the HYUNDAI Forklift distributor to carry out it.

GROUP 2 SPECIFICATIONS

1. MAJOR COMPONENTS



- 1 Mast
- 2 Lift chain
- 3 Lift cylinder
- 4 Carriage and backrest
- 5 Tilt cylinder
- 6 Fork
- 7 Front wheel

- 8 Rear view mirror
- 9 Rear wheel
- 10 Bonnet
- 11 Rear combination lamp
- 12 Preclenaer
- 13 Counterweight
- 14 License lamp (option)

- 15 Beacon lamp (option)
- 16 Camera (option)
- 17 Silencer
- 18 Rear work lamp (option)
- 19 Cabin
- 20 Head and turn signal lamp

2. SPECIFICATIONS



Model		Unit	70D-9VB			
Capacity			kg (lb)	7000 (15500)		
Load center R		mm (in)	600 (2	24")		
Weigh	t(Unloaded)		kg (lb)	10040 (2	22229)	
	Lifting height	А	mm (ft · in)	3030 (9	9' 11")	
	Free lift	В	mm (in)	140 (5	5.5")	
	Lifting speed (Unload/Load)		mm/sec	470/420	(93/83)	
Fork	Lowering speed (Unload/Loa	d)	(ft/min)	500/500	(99/99)	
	$L \times W \times T$	L,W,T	mm (in)	1200×150×65 (47.2×5.9×2.6)		
	Carriage width	N	mm (in)	2068 ((6.9")	
	Tilt angle (forward/backward)	C/C'	degree	15/ ⁻	10	
Mast	Max. height	D	mm (ft · in)	4320 (14' 2")		
	Min. height	Е	mm (ft · in)	2515 (8' 3")		
	Travel speed (Unload)		km/h (mph)	23.7 (*	14.7)	
Body	Gradeability (Load)		%	42.5		
	Min. turning radius (Outside)	F	mm (ft · in)	3436 (1	1' 3")	
ETC	System set pressure		bar (psi)	210 (3050)	*185 (2680)	
Overa	l length	G	mm (ft · in)	3665 (1	12' 0")	
Overa	l width	Н	mm (ft · in)	2088 (6	5' 10")	
Cabin	height	I	mm (ft · in)	2575 (8' 5")	
Groun	d clearance	J	mm (in)	195 (7	7.7")	
Wheel	base	К	mm (ft · in)	2300 (7' 7")	
Wheel	tread front/rear	M/M'	mm (ft · in)	1578 / 1602 (1578 / 1602 (5' 2" / 5' 3")	

 \star : EU, AN corporate sales equipment

3. SPECIFICATION FOR MAJOR COMPONENTS

1) ENGINE

Item	Unit	Specification
Model	_	HMC D4CC
Туре	_	Vertical, 4 cycle DI, EU Stage V diesel engine
Cooling Method	_	Water cooling
Number of cylinders and arrangement	_	4 cylinders, In-line
Firing order	_	1-3-4-2
Combustion chamber type	_	Direct injection
Cylinder bore X stroke	mm (in)	95×102 (3.74×4.02)
Piston displacement	cc (cu in)	2891 (176.4)
Compression ratio	_	15.8 :1
Rated gross horse power	hp/rpm	73.2/2200
Maximum torque at rpm	kgf⋅m/rpm	34.5/1500
Engine oil quantity	ℓ (U.S. gal)	9.1 (2.4)
Dry weight	kg (lb)	266 (586)
High idling speed	rpm	2450
Low idling speed	rpm	850
Rated fuel consumption	g/kWh	207
Starting motor	V-kW	12-2.0
Alternator	V-A	13.5-130
Battery	V-AH	12-100
Fan belt deflection	mm (in)	10~12 (0.40~0.47)
CO ₂	g/kWh	594.2

* This CO₂ measurement results from testing over a fixed test cycle under laboratory conditions a(n) (parent) engine representative of the engine type (engine family) and shall not imply or express any guarantee of the performance of a particular engine.

2) MAIN PUMP

Item	Unit Specification		ication
Туре	_	Axial piston variable pump Gear fixed pump	
Model	_	Casspa MVP	Casspa PLP
Displacement	cc/rev (in ³ /rev)	67 (4.1) 9.17 (0.56)	
Maximum operating pressure	bar (psi)	280 (4060) 250 (3625)	
Rated speed (Max/Min)	rpm	2700/600	
Weight	kgf (lbf)	30 (66.1)	

3) MAIN CONTROL VALVE (MCV)

Item	Unit	Specification
Туре	-	Mono block (3spool), Semi-Mono block (4 / 5spool)
Model	-	Buchholz NG16
Opearating method	-	Hydraulic pilot
Maximum flow rated (lift/lower, tilt)	lpm (U.S. gpm)	170 (45), 60 (16)
Lift/tilt relief valve set pressure (DV1)	bar (psi)	210 (3050)
Attachment oil flow rated (aux1/2/3)	lpm (U.S. gpm)	110 / 110 / 110 (29 / 29 / 29)
Attachment relief valve pressure (DV2)	bar (psi)	140 ~ 190 (2030 ~ 2760)
Built-in accessories valve	-	 Manual fork lowering valve (Emergency function) Adj. max. fork lowering speed, Lower breake valve Overcenter valve (tilt A2), Priority valve (steering)
Weight	kgf (lbf)	3 spool : 28 (61.7), 4 spool : 36 (79.4), 5 spool : 43 (94.8)

4) STEERING UNIT

ltem	Unit	Specification
Туре	_	Load sensing, Non load reaction
Model	_	Sauer Danfoss VSP
Capacity	cc/rev (in ³ /rev)	160 (9.76)
Steering relief valve set pressure	bar (psi)	160 ~ 165 (2320 ~ 2393)
Weight	kgf (lbf)	5.5 (12)

5) CYLINDER

Index		Unit	Specification	
Main lift	V300			85×60×1483 (3.34×2.36×58.4)
Main lift		Tube bore diameter \times	mm (in)	85×60×1483 (3.34×2.36×58.4)
Free lift	1F430	Rod diameter		130×110×767 (5.12×4.33×30.2)
Tilt (15/10 degree)		× Stroke		110×50×338 (4.33×1.97×13.3)
Steering				80×55×150 (3.15×2.16×5.9)
Waight	Lift	V300	kaf (lbf)	66.6 (146.8)
vveight	Tilt	15/10 degree	kyi (ibi)	32.4 (71.4)

6) POWER TRAIN DEVICED

Item			Specification		
Torous converter	Туре		3 Element, 1 stage, 2 phases		
lorque converter	Stall ratio		5.3 : 1		
	Туре		Full auto, power shift		
	Gear shift (F	R/RR)	2/1		
Transmission	Adjustment		Electrical single lever type		
	Overhaul ratio	FR	1:2.456 2:0.946		
		RR	1:2.494		
	Туре		Front-wheel drive type, fixed location		
Axle	Gear ratio		10.668		
	Gear		Ring & pinion gear type		
	Q'ty (FR/RR)		Double : 4/2		
Wheels	Front (drive)		8.25-15-14 PR		
	Rear (steer)		8.25-15-14 PR		
Brokoo	Travel		Front wheel, wet disc brake		
DIAKES	Parking		Wet disc (negative brake)		
Chapting	Туре		Full hydraulic, power steering		
Steening	Steering ang	le	75.87° to both right and left angle, respectively		

NO	Item		Size	kgf ∙ m	lbf ⋅ ft
1		Engine mounting bolt	M10×1.25	7.4±1.4	53.7±10.7
2	Engine	Engine bracket mounting nut	M10×1.5	6.9±1.4	49.9±10.1
3		Radiator mounting bolt, nut	M10×1.5	6.9±1.4	49.9±10.1
4		Hydraulic pump mounting bolt	M16×2.0	29.7±4.5	215±32.3
5		MCV mounting bolt	M 8×1.25	2.5±0.5	18.1±3.6
6	Hydraulic system	Steering unit mounting bolt	M10×1.5	4.0±0.5	28.9±3.6
7		Tilt cylinder; rod-end bolt, nut		23±2	166±14.5
8		Tilt cylinder pin; mounting bolt	M10×1.5	6.9±1.4	50±10.1
9		Transmission mounting bolt, nut	M16×2.0	60.5±5.5	438±39.8
10		Torque converter mounting bolt	M10×1.5	6.9±1.4	50±10
11	Power	Drive axle mounting bolt, nut	M27×3.0	150±15	1085±109
12	system	Propeller shaft (to axle and TM)	3/8-24 UNF	7.0±0.7	50.6±5.1
13		Steering axle mounting bolt, nut	M18×2.5	41.3±6.2	299±44.8
14		Front and rear wheel mounting nut	M22×1.5	62.0±9.3	448±67.3
15		Counterweight mounting bolt	M30×3.5	100±15	723±108
16	Othors	Operator's seat mounting nut	M 8×1.25	2.5±0.5	18.1±3.6
17	Ouners	Cabin mounting bolt	M12×1.75	12.8±3.0	92.6±21.7
18		Mast mounting bolt	M20×2.5	57.9±8.7	419±63

4. TIGHTENING TORQUE FOR MAJOR COMPONENTS

5. TORQUE CHART

Use following table for unspecified torque.

1) BOLT AND NUT

(1) Coarse thread

Dolt oite	8.8T		10	.9T	12.9T	
DOILSIZE	kgf · m	lbf ⋅ ft	kgf · m	lbf ⋅ ft	kgf · m	lbf ⋅ ft
M 6×1.0	0.8 ~ 1.2	5.8 ~ 8.6	1.2 ~ 1.8	8.7 ~ 13.0	1.5 ~ 2.1	10.9 ~ 15.1
M 8×1.25	2.0 ~ 3.0	14.5 ~ 21.6	2.8 ~ 4.2	20.3 ~ 30.4	3.4 ~ 5.0	24.6 ~ 36.1
M10×1.5	4.0 ~ 6.0	29.0 ~ 43.3	5.6 ~ 8.4	40.5 ~ 60.8	6.8 ~ 10.0	49.2 ~ 72.3
M12×1.75	6.8 ~ 10.2	50.0 ~ 73.7	9.6 ~ 14.4	69.5 ~ 104	12.3 ~ 16.5	89.0 ~ 119
M14×2.0	10.9 ~ 16.3	78.9 ~ 117	16.3 ~ 21.9	118 ~ 158	19.5 ~ 26.3	141 ~ 190
M16×2.0	17.9 ~ 24.1	130 ~ 174	25.1 ~ 33.9	182 ~ 245	30.2 ~ 40.8	141 ~ 295
M18×2.5	24.8 ~ 33.4	180 ~ 241	34.8 ~ 47.0	252 ~ 340	41.8 ~ 56.4	302 ~ 407
M20×2.5	34.9 ~ 47.1	253 ~ 340	49.1 ~ 66.3	355 ~ 479	58.9 ~ 79.5	426 ~ 575
M22×2.5	46.8 ~ 63.2	339 ~ 457	65.8 ~ 88.8	476 ~ 642	78.9 ~ 106	570 ~ 766
M24×3.0	60.2 ~ 81.4	436 ~ 588	84.6 ~ 114	612 ~ 824	102 ~ 137	738 ~ 991
M30×3.5	120 ~161	868 ~ 1164	168 ~ 227	1216 ~ 1641	202 ~ 272	1461 ~ 1967

(2) Fine thread

Dolt oizo	8.8T		10	.9T	12.9T	
DOILSIZE	kgf · m	lbf ⋅ ft	kgf · m	lbf ⋅ ft	kgf · m	lbf ⋅ ft
M 8×1.0	2.1 ~ 3.1	15.2 ~ 22.4	3.0 ~ 4.4	21.7 ~ 31.8	3.6 ~ 5.4	26.1 ~ 39.0
M10×1.25	4.2 ~ 6.2	30.4 ~ 44.9	5.9 ~ 8.7	42.7 ~ 62.9	7.0 ~ 10.4	50.1 ~ 75.2
M12×1.25	7.3 ~ 10.9	52.8 ~ 78.8	10.3 ~ 15.3	74.5 ~ 110	13.1 ~ 17.7	94.8 ~ 128
M14×1.5	12.4 ~ 16.6	89.7 ~ 120	17.4 ~ 23.4	126 ~ 169	20.8 ~ 28.0	151 ~ 202
M16×1.5	18.7 ~ 25.3	136 ~ 182	26.3 ~ 35.5	191 ~ 256	31.6 ~ 42.6	229 ~ 308
M18×1.5	27.1 ~ 36.5	196 ~ 264	38.0 ~ 51.4	275 ~ 371	45.7 ~ 61.7	331 ~ 446
M20×1.5	37.7 ~ 50.9	273 ~ 368	53.1 ~ 71.7	384 ~ 518	63.6 ~ 86.0	460 ~ 622
M22×1.5	51.2 ~ 69.2	370 ~ 500	72.0 ~ 97.2	521 ~ 703	86.4 ~ 116	625 ~ 839
M24×2.0	64.1 ~ 86.5	464 ~ 625	90.1 ~ 121	652 ~ 875	108 ~ 146	782 ~ 1056
M30×2.0	129 ~ 174	933 ~ 1258	181 ~ 245	1310 ~ 1772	217 ~ 294	1570 ~ 2126

2) PIPE AND HOSE (FLARE TYPE)

	Thread	Hex. across flat	Tightening torque		
HOSE SIZE	(PF)	(mm)	kgf∙m	lbf·ft	
1/4"	1/4	19	4	28.9	
3/8"	3/8	22	5	36.2	
1/2"	1/2	27	9.5	68.7	
3/4"	3/4	36	18	130.2	
1"	1	41	21	151.9	
1-1/4"	1-1/14	50	35	253.2	

3) PIPE AND HOSE (ORFS TYPE)

	Thread	Hex. across flat	Tightening torque			
HOSE SIZE	(UN/UNF/UNS)	(mm)	kgf⋅m	lbf·ft		
1/4"	9/16-18	19	3	21.7		
3/8"	11/16-16	22	5	36.2		
1/2"	13/16-16	24	7	50.6		
5/8"	1-14	30	12	86.8		
3/4"	1-3/16-12	36	18	130.2		
1"	1-7/16-12	41	23	166.4		
1-1/4"	1-11/16-12	50	28	202.5		
1-1/2"	2-12	58	32	231.1		

4) FITTING (O-RING SEAL TYPE)

	Thread	Hex. across flat	Tightening torque		
HOSE SIZE	(UN/UNF)	(mm)	kgf∙m	lbf·ft	
1/4"	7/16-20	17	2	14.5	
3/8"	9/16-18	19	3	21.7	
1/0"	2/4 16	22	4	28.9	
1/2	3/4-10	24	6	43.4	
E /01	7/8-14	27	10	72.3	
0/0		30	12	86.8	
0/4"			15	108.5	
3/4	1-1/10-12	36	18	130.2	
1"	1-5/16-12	41	23	166.4	
1-1/4"	1-5/8-12	50	28	202.5	
1-1/2"	1-7/8-12	55	32	231.5	

5) BAND CLAMP

Tag No. Hose size		Band width	Tightening torque		
iag ivo.	(mm)	(mm)	kgf∙m	lbf·ft	
S20-15	8 ~ 14		0.2	0.17	
S20-17	11 ~ 17		0.3	2.17	
S20-22	13 ~ 20	9			
S20-25	15 ~ 24		0.35	0.50	
S20-28	19 ~ 28			2.53	
S20-32	22 ~ 32	12			
S20-40	26 ~ 38	0	0.42	2.04	
S20-45	32 ~ 44	9	0.42	3.04	

6) BAND CLAMP (IDEAL, FLEX GEAR TYPE)

Tog No	Hose size	Band width	Tightenir	ing torque		
lag No.	(mm)	(mm)	kgf∙m	lbf·ft		
41-212	32 ~ 54					
41-262	45 ~ 67					
41-312	57 ~ 79					
41-362	40 ~ 92	15.9	1.1	8.0		
41-412	83 ~ 105					
41-462	95 ~ 117					
41-512	108 ~ 130					

6. WRENCH AND SPANEER CHART

	Wi	rench & Span	ner	Thread			PIPE AND HOSE	
No.	in	ch	mm	UNF/UN	М	PF/G	ORFS (UNF/UN)	FLARE (PF)
1	-	0.050	1.3	-	-	-	-	-
2	-	0.059	1.5	-	-	-	-	-
3	1/16	0.063	1.6	-	-	-	-	-
4	5/64	0.078	2	-	-	-	-	-
5	3/32	0.094	2.4	-	-	-	-	-
6	-	0.098	2.5	-	-	-	-	-
7	7/64	0.109	2.8	-	-	-	-	-
8	-	0.118	3	-	-	-	-	-
9	1/8	0.125	3.2	-	-	-	-	-
10	9/64	0.141	3.5	-	-	-	-	-
11	5/32	0.156	4	-	-	-	-	-
12	-	0.177	4.5	-	-	-	-	-
13	3/16	0.188	4.8	-	-	-	-	-
14	-	0.197	5	-	-	-	-	-
15	13/64	0.203	5.2	-	-	-	-	-
16	7/32	0.219	5.5	-	-	-	-	-
17	15/64	0.234	6	-	-	-	-	-
18	1/4	0.250	6.4	-	-	-	-	-
19	17/64	0.266	6.8	-	-	-	-	-
20	9/32	0.281	7	-	-	-	-	-
21	5/16	0.313	8	-	-	-	-	-
22	11/32	0.344	8.7	-	-	-	-	-
23	-	0.354	9	-	-	-	-	-
24	3/8	0.375	9.5	-	-	-	-	-
25	-	0.394	10	-	-	-	-	-
26	-	-	11	-	-	-	-	-
27	7/16	0.438	11.1	-	-	-	-	-
28	15/32	0.469	12	-	-	-	-	-
29	1/2	0.500	12.7	-	-	-	-	-
30	-	-	13	-	-	-	-	-
31	17/32	0.53	13.5	-	-	-	-	-
32	-	0.55	14	7/16-20	-	-	-	-
33	9/16	0.56	14.3	-	-	-	-	-
34	19/32	0.59	15	-	-	-	-	-
35	5/8	0.63	15.9	-	-	-	-	-
36	-	-	16	-	-	-	-	-
37	21/32	0.66	16.7	-	-	-	-	-

	W	rench & Span	ner	Thread			PIPE AND HOSE	
No.	in	ch	mm	UNF/UN	М	PF/G	ORFS (UNF/UN)	FLARE (PF)
38	-	-	17	-	M12	-	-	-
39	11/16	0.69	17.5	-	-	-	-	-
40	-	-	18	-	-	-	-	-
41	3/4	0.75	19	9/16-18	M14	G1/4	9/16-18	PF1/4
42	25/32	0.78	19.8	-	-	-	-	-
43	-	-	20	-	-	-	-	-
44	13/16	0.81	20.6	-	-	-	-	-
45	-	-	21	-	-	-	-	-
46	-	-	22	-	M16	G3/8	11/16-16	PF3/8
47	7/8	0.88	22.2	-	-	-	-	-
48	29/32	0.91	23	-	-	-	-	-
49	15/16	0.94	23.8	-	-	-	-	-
50	-	-	24	3/4-16	M18	-	13/16-16	-
51	31/32	0.97	26.4	-	-	-	-	-
52	-	-	25	-	-	-	-	-
53	1	1.00	25.4	-	-	-	-	-
54	-	-	26	-	-	-	-	-
55	1 1/16	1.06	27	7/8-14	M22	G1/2	-	PF1/2
56	-	-	28	-	-	-	-	-
57	1 1/8	1.13	28.6	-	-	-	-	-
58	-	-	29	-	-	-	-	-
59	-	-	30	-	-	-	1-14	-
60	1 3/16	1.19	30.2	-	-	-	-	-
61	-	-	31	-	-	-	-	-
62	1 1/4	1.25	31.8	-	-	-	-	-
63	-	-	32	1-1/16-12	M24	G3/4	-	-
64	-	-	33	-	-	-	-	-
65	1 5/16	1.31	33.3	-	-	-	-	-
66	-	-	34	-	-	-	-	-
67	1 3/8	1.38	35	-	-	-	-	-
68	-	-	36	1-3/16-12	M27	G3/4	1-3/16-12	PF3/4
69	1 7/16	1.44	37	-	-	-	-	-
70	1 1/2	1.50	38	-	-	-	-	-
71	-	-	39	-	-	-	-	-
72	1 9/16	1.56	39.7	-	-	-	-	-
73	-	-	40	-	-	-	-	-
74	-	-	41	1-5/16-12	M33	G1	1-7/16-12	PF1
75	1 5/8	1.63	41.3	-	-	-	-	-

	W	Wrench & Spanner Thread		Thread			PIPE AND HOSE	
No.	in	ch	mm	UNF/UN	UNF/UN M PI		ORFS (UNF/UN)	FLARE (PF)
76	1 11/16	1.69	43	-	-	-	-	-
77	1 3/4	1.75	44	-	-	-	-	-
78	1 13/16	1.81	46	-	-	-	-	-
79	1 7/8	1.88	47.6	-	-	-	-	-
80	-	-	48	-	-	-	1-11/16-12	-
81	1 15/16	1.94	49.2	-	-	-	-	-
82	-	-	50	1-5/8-12	-	G1-1/4	-	PF1-1/4
83	2	2.00	50.8	-	-	-	-	-
84	-	-	51	-	-	-	-	-
85	2 1/8	2.13	54	-	-	-	-	-
86	-	-	55	1-7-8-12	-	G1-1/2	-	PF1-1/2
87	-	-	57	-	-	-	2-12	-
88	2 1/4	2.25	57.2	-	-	-	-	-
89	-	-	60	-	-	-	-	-

7. RECOMMENDED LUBRICANTS

Use only oils listed below or equivalent.

Do not mix different brand oil.

Sanvice point Kind of fluid Capacity ℓ		Ambient temperature °C(°F)									
Service point	Kind of fluid	(U.S. gal)	-50 (-58)	-30 (-22)	-2 (-4	0 - ⁻ 4) (1	10 4) (32	0 10 2) (50) 20)) (68) 30) (86)	40 (104)
					*S/	AE 5W	-40				
						SAE	10W				
Engine oil	Engine oil	01(24)					SA	E 10W-	-30		
pan		9.1 (2.4)		[SAE 5V	V-30		
								SAE 1	5W-40		
									SAE	E 30	
Torque	Transmission	/>									
converter transmission	oil	20 (5.3)				9	bell dor) Sr		
					Hu	yndai c	ilbank >	teer TH	IF 75W-	80	
Axle	Gear oil	12.5 (3.3)									
Hydraulic		125 (33)				*IS	O VG 1	5			
OILITIK	Hydraulic					19	SO VG (32			
	oil						l	SO VG	46		
pump		0.7 (0.2)						15	SO VG 6	68	
				*AS	TM	D975 N	NO.1				
Fuel tank	Diesel fuel*1	171.5 (45.3)						ASTA	/ D975	NO 2	
				_							
Fitting	Grosso					*NLG	INO.1	1			
(Grease nipple)	Grease	-						N	LGI NO	.2	
					_						
Radiator	Antifreeze :	12.5 (3.3)				Ethyler	ne glyco	l base p	ermane	nt type (50:50)
riddiator	Water	Water	*Ethyler	ne glycol b	ase pe	ermanent ty	rpe (60 : 40)				

NOTES :

- Engine oil should be ACEA classification C2/C3.
- Change the type of engine oil according to the ambient temperature.
- When using oil of different brands from the previous one, be sure to drain all the previous oil before adding the new engine oil.
- ★1 : Ultra low sulfur diesel
- ★ : Cold region
- sulfur content \leq 15 ppm
- Russia, CIS, Mongolia

GROUP 3 PERIODIC REPLACEMENT

For operation safety, never fail to perform periodic maintenance or make periodic replacement of the consumable parts listed in the following.

These parts may deteriorate in time and are susceptible to wear. It is difficult to estimate the degree of wear at time of periodic maintenance; therefore, even if no apparent wear is found, always replace with new parts within the prescribed period of replacement (Or earlier if trouble is found). Note that periodic replacement has nothing to do with guarantee service.

No.	Periodical replacement of safety parts	Interval		
1	Lift cylinder hose			
2	Tilt cylinder hose	Every 1 year (harsh operation)		
3	Side shift cylinder hose	Every 2 years (normal operation)		
4	Brake hose			
5	Hydraulic pump hose			
6	Power steering hose	Every 2 years		
7	Coolant hose and clamps			
8	Fuel hose	Even (2) years (bareh eneration)		
9	Packing, seal, and O-ring of steering cylinder	Every 2 years (narsh operation)		
10	Lift chain	Every 4 years (normal operation)		
11	Hydraulic pump seal kit	Every 3 years		
12	Pressure sensor	Every 5 years		
13	Mast accmulator (piston type)	Every 10 years		

* Replace the O-ring and gasket at the same time when replacing the hose.

- * Replace clamp at the same time if the hose clamp is cracked when checking and replacing hose.
- ※ Normal operation

· Eight hour material handling, mostly in buildings or in clean, open air on clean paved surfaces.

- ※ Harsh operation
 - · All harsh working environment
 - · Long term heavy load operation
 - · High and low temperature working environment
 - · Sudden change in temperature
 - · Dusty or sandy working environment
 - · Highly corrosive chemical working environment
 - · Damp working environment