

CHAPTER 1 SAFETY HINTS

1. Daily Inspection	1-1
2. Do's and don'ts	1-2
3. No riders	1-4
4. Pedestrians	1-5
5. Operator Protection	1-6
6. Fork Safety	1-7
7. Pinch points	1-8
8. Safe operation during cargo loading	1-9
9. Grades, ramps, slopes and inclines	1-10
10. Tip over	1-11
11. Surface and capacity	1-12
12. Parking	1-13
13. Lifting, jack-up and blocking	1-14
14. Lifting of lift truck	1-18

CHAPTER 2 OPERATING HAZARDS

1. Loose loads	2-1
2. Long and wide loads	2-2
3. Caution on turning	2-2
4. Low overhead clearance	2-3
5. Fast turns and high loads	2-3
6. Right angle stacking	2-4
7. Chain slack	2-4
8. Pallets and skids	2-5
9. Caution for electrical lines	2-5
10. Solid tire	2-6

CHAPTER 3 KNOW YOUR TRUCK

1. General locations	3-1
2. Equipment nameplate and label	3-2
3. Cluster and control devices	3-5
4. Cluster	3-6
5. Switches and levers	3-15
6. Battery connector	3-17
7. Support and safety parts	3-17

CHAPTER 4 OPERATOR MAINTENANCE AND CARE

1. Daily safety inspection	4-1
2. Visual inspection	4-2
3. Function inspection	4-3
4. Actions on inspection results	4-3

CHAPTER 5 STARTING AND OPERATING PROCEDURES

1. Before operating the truck	5-1
2. Starting from a safe condition	5-1
3. Traveling of the truck	5-2
4. Speed adjustment	5-4
5. Brake operation	5-4
6. Plugging	5-4
7. Operating safely	5-6
8. Load handling	5-8
9. Shut down procedure	5-14

CHAPTER 6 PLANNED MAINTENANCE

1. Introduction	6-1
2. Safe maintenance practices	6-2
3. Planned maintenance intervals and operating condition	6-4
4. Parts positions	6-5
5. Daily maintenance check	6-6
6. Planned maintenance intervals	6-7
7. Visual inspection	6-8
8. How to perform planned maintenance	6-10
9. Bolt tightening torque inspection	6-16
10. Air cleaning	6-16
11. Battery maintenance	6-17
12. Storage	6-23
13. Oil	6-24

CHAPTER 7 SPECIFICATIONS

1. Dimensions and performances	7-1
2. Specifications for major components	7-3
3. Tightening torque	7-7