

CONTENTS

A message to hyundai lift truck operators	0-1	11. Solid tire	2-7
Introduction	0-2	12. Weight indicator (option)	2-7
How to use this manual	0-3		
Safety label	0-5	3. KNOW YOUR TRUCK	
Guides on use	0-12	1. General locations	3-1
Integrated call center	0-14	2. Name plate	3-2
Sales distributors	0-15	3. Cab devices	3-3
Authorized service shops	0-16	4. Cluster	3-4
Parts distributors	0-17	5. Switches and levers	3-12
		6. Cab control devices	3-18
		7. Battery cover	3-19
		8. Air conditioner and heater (optional)	3-19
1. SAFETY HINTS		4. OPERATOR MAINTENANCE AND CARE	
1. Daily inspection	1-1	1. Daily safety inspection	4-1
2. Do's and don'ts	1-2	2. Apparent shape inspection	4-2
3. Seat belts	1-4	3. Function inspection	4-3
4. No riders	1-5	4. Actions on inspection results	4-3
5. Pedestrians	1-6		
6. Operator protection	1-7	5. STARTING AND OPERATING PROCEDURES	
7. Fork safety	1-8	1. Before operating the truck	5-1
8. Pinch points	1-9	2. Starting from a safe condition	5-1
9. Travel	1-10	3. Traveling of the truck	5-2
10. Grades, ramps, slopes and inclines	1-11	4. Speed adjusting	5-4
11. Tip over	1-12	5. Brake operation	5-4
12. Surface and capacity	1-14	6. Plugging	5-4
13. Parking	1-15	7. Operating safely	5-5
14. Lifting, jack-up and blocking	1-16	8. Load handling	5-7
15. Lifting of forklift truck	1-21	9. Shut down procedure	5-13
16. Side shift and fork positioner (optional)	1-22		
2. OPERATING HAZARDS		6. EMERGENCY PROCEDURES	
1. Loose loads	2-1	1. Hauling	6-1
2. Long and wide loads	2-2	2. Emergency mast lowering	6-3
3. Rear swing	2-2		
4. Low overhead clearance	2-3	7. PLANNED MAINTENANCE AND LUBRICATION	
5. Fast turns and high loads	2-3	1. Introduction	7-1
6. Drop-offs	2-4	2. Safe maintenance practices	7-2
7. Right angle stacking	2-4	3. Basics	7-4
8. Chain slack	2-5	4. Parts positions	7-7
9. Pallets and skids	2-5		
10. Caution for electrical lines	2-6		

5. Regular maintenance	7-9
6. Planned maintenance intervals	7-10
7. How to perform planned maintenance ...	7-11
8. Apparent shape inspection	7-15
9. Exchange of lubricant and consumables	7-18
10. Torque inspection	7-20
11. Air cleaning	7-20
12. Battery maintenance	7-21
13. Battery handling	7-22
14. Battery charging	7-23
15. Battery exchanging	7-25
16. Battery maintenance	7-30
17. Lithium ion battery (option)	7-31
18. Lithium ion battery recharger (option)	7-33
19. Storage	7-35
20. Lubricants for new truck	7-36
21. Recommended lubricants	7-36

8. SPECIFICATIONS

1. Specification table	8-1
2. Specification for major components	8-2
3. Tightening torque	8-5